













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod


















**A**

**S504-SFW1K/4/11**





A	B	C1	C2	C3	D
1	S504-0011	403	1046	16	1/1
2	S504-1008	377	330	15	1/1
3	S504-1009	377	330	15	1/1
4	S504-1010	377	100	15	1/1
5	S504-2007	1050	330	15	1/1
6	S504-2008	1050	330	15	1/1
7	S504-5704	795	100	6,	1/1
8	S504-9001	387	1029,	2,5	1/1
9	S504-7351	795	100	6,	1/1














2









3





4



5



6

**Pflegehinweis!**

Bitte nur mit einem Staubtuch  
(kein Microfasertuch) oder  
einem feuchten Lappen reinigen.  
KEINE scheuernden Putzmittel  
verwenden!

**Wskazówka dotycząca pielęgnacji!**

Proszę czyścić tylko suchą lub lekko  
wilgotną szmatką do kurzu. Nie używać  
żadnych środków szorstkich!

