

















Biurko wyłącznie do montażu przy ścianie
Desk for wall mounting only
Schreibtisch unbedingt an der Wand befestigen





















Nr				PSC
1	780	200	16	1
2	780	500	16	1
3	734	182	16	1
4	724	120	16	1
5	734	182	16	1
6	724	120	16	1
7	290	230	16	1
8	290	230	16	1
9	718	300	16	1





1








5






6



7



8



9

